

Feature	Remote Starter Brand/Model#												Definition
	JBS/Alert	Alert						Bulldog					
	150R	250R	350R	450R	550R	650R	750R	RS82	RS1100	RS1200E	RS1300E	Deluxe 500	
Add-on Remote Start	X												
Remote Start Only		X			X			X					
Remote Start w/Keyless Entry			X	X					X	X		X	
Remote Start w/Security System						X	X				X		
Remotes Included		1	1	2	1	2	2	1	1	2	2	1	
# Buttons		2	3	4	5	4	4	2	4	4	4	5	
LCD Display, Audio & Vibrate	-	-	-	-	Yes	-	Yes (1)	-	-	-	-	Yes	
Range	N/A	500'	500'	1000'	2000'	1000'	2000'	400'	400'	800'	800'	1/2 Mile	
Run Time in 5-min. increments	5-30	5-30	5-30	5-30	5-30	5-30	5-30	15	5-15	5-25	5-25	5-30	
Number of Remotes Programmable	-	4	4	4	4	4	4	4	4	4	4	4	
Remote Learning	-	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Lets the unit learn a New remote without removing the unit from under the dash
Automatic Cold Start	-	-	-	-	-	-	-	-	Yes	Yes	Yes	Yes	Vehicle starts at set temperature
Automatic Hot Start	-	-	-	-	-	-	-	-	-	-	Yes	Yes	Vehicle starts at set temperature
Automatic Start	-	-	-	-	-	-	-	-	-	Yes	Yes	Yes	Will start vehicle at a pre-programmed time
Panic	-	-	Yes	Yes	Yes	Yes	Yes	-	-	-	-	Yes	The alarm will go into full blown security mode when you hit the panic button
Diesel Start Capability	Yes	Yes	Yes	Yes	Yes	Yes	Yes	-	-	-	-	Yes	Compatible with Diesel engines
Diesel Engine Warm-up Timer (10/15/20 sec.)	-	Yes	Yes	Yes	Yes	Yes	Yes	-	-	-	-	-	
Standard Transmission Capable	-	-	-	Yes	Yes	Yes	Yes	-	-	-	-	Yes	Suitable for vehicles with standard transmissions
Keyless Entry	-	-	Yes	Yes	Yes	Yes	Yes	-	Yes	Yes	Yes	Yes	Remote locking/unlocking of door locks
Programmable Chirps On/Off	-	-	Yes	Yes	Yes	Yes	Yes	-	-	-	-	-	Will operate the door locks
Ignition Controlled Auto Locking On/Off	-	-	Yes	Yes	Yes	Yes	Yes	-	-	-	-	Yes	
In-vehicle Temperature Monitor	-	-	-	-	Yes	Yes	Yes	-	-	-	-	Yes	Monitors temperature inside vehicle
Temperature Sensing Start	-	-	-	-	Yes	Yes	Yes	-	-	-	-	Yes	Vehicle will start at set temperature
Timer Control Automatic Start	-	Yes	Yes	Yes	Yes	Yes	Yes	-	-	-	-	-	Vehicle will start after set period of time
Remote Car Finder	-	-	-	Yes	Yes	Yes	Yes	-	-	-	-	Yes	Will sound the horn or siren rapidly eight times to locate your vehicle
Dedicated Start and Stop Buttons	-	-	-	-	-	-	-	Yes	Yes	Yes	Yes	-	Separate buttons to start and stop engine

Starter Disable	-	-	-	Yes	Yes	Yes	Yes	-	-	-	(-)	(-)	Will cut of the starter when the system is armed
Dome Light Supervision	-	-	(-)	(-)	(-)	(-)	(-)	-	(+/-)	(+/-)	(+/-)	(-)	A transistorized output for illuminating the interior lights when unlocking the doors
Trunk Output	-	-	-	(-)	(-)	(-)	(-)	-	(+/-)	(+/-)	(+/-)	(-)	A transistorized out put for hooking to the trunk or sliding van door
Child Safety Start Mode	-	-	Yes	Yes	Yes	Yes	Yes	-	-	-	-	Yes	Can program the transmitter to remote start by pressing two or more buttons and the same time to prevent accidental starts
Safety Shutdown for Brake	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Engine stops when brake peddle is depressed
Safety Shutdown for Hood	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Engine stops when hood is opened
Tach Sensing or Voltage Sensing	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Tach sensor or voltage sensor is used to determine if vehicle is running
Oil Sending Unit Pressure Check Sensing	-	Yes	Yes	Yes	Yes	Yes	Yes	-	-	-	-	-	Determines when the oil pressure has risen to stop cranking the starter
Turbo Charge Mode	-	Yes	Yes	Yes	Yes	Yes	Yes	-	-	-	-	Yes	Will allow the vehicle to continue running after you exit to cool down the turbo charger
Tach Learn	-	-	-	-	-	-	-	-	Yes	Yes	Yes	Yes	Will learn the tach signal to ensure the remote starter stops cranking
Parking Light Output (R= Onboard Relay)	(-)	(-)	(+/-)R	(+/-)R	(+/-)R	(+/-)R	(+/-)R	(+/-)	(+/-)	(+/-)	(+/-)	(+/-)	There is a wire designated for parking light output
On-board Relay for the Door Locks	-	-	-	-	-	-	-	-	Yes	Yes	Yes	Yes	All the relays are built in for every type of door locks
Input for Additional Sensors	-	-	-	-	-	-	-	-	-	-	1	0	Additional inputs for sensor such as glass breakage or motion
Ignition Three Negative	-	-	-	-	-	-	-	(-)	(-)	(-)	(-)	(-)	For vehicle that have more then two ignition wires
Plug-in L.E.D.	-	-	-	-	-	-	-	-	-	-	-	Yes	A dash mounted light that blinks when the system is armed
Plug-in Override Switch	-	-	-	-	-	-	-	-	-	-	-	Yes	To disable the alarm or starter functions when needed
Window-mount Receiver	-	-	-	-	-	-	-	-	-	-	-	Yes	The unit that receives a signal when the transmitter is pressed
Extended Range Antenna	-	-	-	-	-	-	-	-	-	Yes	Yes	-	Extends the antenna from the control module to the windshield for longer distance
L.E.D. Indicator	-	-	-	-	Yes	Yes	Yes	-	-	-	-	Yes	Will indicate what zone has been tampered with upon disarm
Siren Output	-	-	-	-	-	Yes	Yes	-	-	-	Yes	-	An output for adding additional sirens
Six-tone Mini Siren	-	-	-	-	-	Yes	Yes	-	-	-	-	-	Six-tone siren included
Horn Output	-	(-)	(-)	(-)	(-)	(-)	(-)	-	-	-	Yes	Yes	A transistorized output for hooking to the vehicles horn

